




Text input for screens


Getting Started

'this'

Place your finger near the first letter of the word and without lifting, trace over all the letters in the word.

Spaces are added automatically – just pick up your finger and start the next word.



For a tutorial or more help, press and hold the  key.

Almost done with errands.
meet at the **case?**





Corrections

To correct a word, double tap on it and a word choice box will appear.

Select the correct word and the cursor will return to the end of the sentence to resume swyping.

Almost done with errands.
meet at the **case?**



Double Letter

'cool'

Squiggle or make a loop on the letter to double it!

Apostrophe

'can't'

Swype over the apostrophe key to add it to a word.

Capitalization

'The'

Swype above the keyboard to capitalize the preceding letter.